


## TV Instructions



1. Turn on TV




2. TV Needs to be set to HDMI  
3, to select this use this button  
Then the arrows in middle of remote  
And the centre button in the middle of  
The arrow to select



3. Turn on Box



4. The box is under the TV  
When on, the light is white



5. You should see this screen



5. To see the channel list as per 5 press OK  
then use arrows up and down to select  
channel and press OK  
again

If you can't get internet or TV at all, please check the extensión lead is plugged in on the wall. Sometimes this maybe unplugged in error