

TV Instructions



Turn on TV




If the red light is on the
Box is off



Using this remote
turn on the box



The box should then look like this



To change the channels press OK
Use the arrows to select a different
Channel and press OK again which
Will put it on the main screen. To
Get back to programme list press
Ok again