


Washing Machine Instructions



- | | |
|-------------------|--------------------------|
| 1. Start | 9. Wool |
| 2. Program status | 10. Additional Spin |
| 3. Finished | 11. Cotton |
| 4. Spin Dry | 12. Intensive 60 degrees |
| 5. Clarify | 13. Pre clean |
| 6. Wash | |
| 7. Synthetics | |
| 8. Delicates | |